

Lecture 11
Input Capture Mode

This material is developed by IMTSchool for educational use only
All copyrights are reserved








ICU


The input capture unit (ICU) is a peripheral that used to identify the parameters of an input PWM signal. ICU receives an input PWM signal and detects its frequency and duty cycle.







In the microcontroller world, the ICU may be a **stand alone peripheral** or a **mode of a timer** or it may be not exist. If the ICU peripheral is not exist in the microcontroller, we still can implement the functionality using **External Interrupt Peripheral and Normal Timer**.





Introduction to PWM

This method doesn't require a dedicated peripheral for the ICU, it uses a normal timer and a external interrupt peripheral with the following algorithm:

PWM Signal

> Microcontroller EXTI

- Apply the PWM signal to be measure on the EXTI pin while configuring the EXTI mode to be rising edge detection.
- At the first rising edge, an interrupt would be generated, inside the ISR do the following:
 - Enable the timer to start count.
 - Configure the EXTI to detect falling edge
- With the falling edge, another interrupt would be generated, inside the ISR do the following:
 - Read the value of the timer and save it in a variable called Ton
 - Reset the timer to count from 0 again
 - Configure the EXTI to detect rising edge
- With the next rising edge, and interrupt would be generated, inside the ISR do the following:
 - Read the value of the timer and save it in a variable called Toff



Introduction to PWM

- Start Timer
- Configure EXTI mode to be falling edge

Interrupt 1

- Save Ton
- Reset Timer

Ton


 Configure EXTI mode to be rising edge Interrupt 2 • Save Toff

Interrupt 3

Toff











LAb₁





LAb 2







The End







www.imtschool.com



www.facebook.com/imaketechnologyschool/

This material is developed by IMTSchool for educational use only

All copyrights are reserved